



### MORMI 2J RNAV

**DEP RWY17:** ASC directo a AT030, viraje izquierda TR169° hacia AT250 - AT487 - MORMI. Cruzar AT030 a 1600Ft o superior, AT250 a 8000 Ft o superior, AT487 a FL150 o superior, MORMI a FL170 o superior, luego según autorización ATC.

**TAKE-OFF RWY17:** Climb direct to AT030, turn left on TR169° to AT250 - AT487 - MORMI. Cross AT030 at or above 1600FT, AT250 at or above 8000 Ft, AT487 at or above FL150, MORMI at or above FL170, then according to ATC clearance.

### MORMI 2K RNAV

**DEP RWY35:** ASC directo a AT040, viraje derecha directo a AT142, posterior continuar en TR176° hacia AT442 - MORMI. Cruzar AT140 a 2000Ft o superior, AT142 a 5000 Ft o superior, AT442 a FL110 o superior, MORMI a FL170 o superior, luego según autorización ATC.

**TAKE-OFF RWY35:** Climb direct to AT040, turn right direct to AT142, then continue on TR176° to AT442 - MORMI. Cross AT040 at or above 2000FT, AT142 at or above 5000 Ft, AT442 at or above FL110, MORMI at or above FL170, then according to ATC clearance.