



REPUK 2J

DEP RWY 01: Ascender directo a IQQ VOR. Cruzar IQQ VOR a 3000FT o superior para interceptar y ascender en R344 IQQ VOR hasta 8000 Ft, luego según autorización ATC.

TAKE-OFF RWY 01: Climb direct to IQQ VOR. Cross IQQ VOR at or above 3000FT to intercept and climb on R344 IQQ VOR until 8000 Ft, then continue according to ATC clearance.

DASA / SECCION AIS-MAP