



LOBAG 1 / REPUK 2K RNAV

DEP RWY 19: Ascienda en TR187° hasta 600FT viraje derecha directo a DA357, posterior...

TAKE-OFF RWY 19: Climb on TR187° until 600 FT, then turn right direct to DA357, then...

LOBAG 1: Directo a LOBAG para interceptar AWY U/T-291. Cruce LOBAG FL130 o superior.

LOBAG 1: Direct to LOBAG to intercept AWY U/T-291. Cross LOBAG at or above FL130.

REPUK 2K: Directo a REPUK para interceptar AWY's V-200 / U/L-300 . Cruce REPUK 8000 Ft o superior.

REPUK 2K: Direct to REPUK to intercept AWY's V-200 / U/L-300. Cross REPUK at or above 8000 Ft.