



Nivel de Transición by ATC
 Transition Level by ATC

No se ajusta a escala / Not to scale

STAR OPURA 2B / UDOVI 2B

OPURA 2B: En OPURA INT viraje izquierda para interceptar R338 (TR158°) hasta D23 BAL, luego viraje derecha para orbitar D20 hasta interceptar R298. Cruzar OPURA INT FL100 o superior, D30 FL100 o superior. Continuar descenso para 7000Ft o según autorización ATC.

OPURA 2B: At OPURA INT left turn to intercept R338 (TR158°) until D23 BAL, then turn right to join D20 until intercept R298. Cross OPURA INT at or above FL100, D30 at or above FL100. Continue descent to 7000Ft or according to ATC clearance.

UDОВI 2B: Desde UDOVI INT continuar en R338 (TR158°) hasta D23 BAL, luego viraje derecha para orbitar D20 hasta interceptar R298. Cruzar UDOVI INT FL110 o superior, D30 FL100 o superior. Continuar descenso para 7000FT o según autorización ATC.

UDОВI 2B: From UDOVI INT continue on R338 (TR158°) until D23 BAL, then turn right to join D20 until intercept R298. Cross UDOVI INT at or above FL110, D30 at or above FL100. Continue descent to 7000FT or according to ATC clearance.